



PARTS LIST		
ITEM	QTY	PART NUMBER
1	2	Pump
2	2	Reducing Bush (10HM Model Only)
3	2	Nipple
4	2	M/F Union
5	2	Suction Isolation Valve
6	2	Discharge Isolation Valve
7	1	1" to 1/4" Reducing Bush
8	1	Discharge Manifold
9	1	Suction Manifold
10	1	Pressure Vessel
11	2	1/4" Blanking Cap
12	1	1/4" Blanking Plug
13	1	Pressure Gauge
14	4	3 Piece Union
15	1	Flowthrough Iso Drain Valve
16	2	Variable Speed Controller
17	1	Consumer Box
18	1	1/2" Blanking Plug
19	1	Base Plate
20	1	Discharge End Cap
21	1	Suction End Cap

NOTE
ALL
DIMENSIONS
ARE IN MM'S
TYPICAL ONLY
- NON
BINDING



E-Series Twin Booster - Exploded

DRAWN BY
Ben

DATE
14/09/2021

SHEET
1 / 1